

# VMS (Video Management System) user instructions

# table of Contents


table of Contents.....	1
1 Installation.....	2
2 VMS usage and operating instructions.....	3
2.1 server and operating instructions.....	3
2.1.1 Login.....	3
2.1.2 Adding a hardware device.....	5
2.1.2.1 Adding scanning equipment.....	6
2.1.2.1.1 specified IP range scanning hardware.....	6
2.1.2.1.2 specify scanning hardware manufacturers.....	7
2.1.2.1.3 Configuring automatic verification.....	7
2.1.2.1.4 Start Depending on how the search appliance.....	8
2.1.2.1.5 Manual Verification hardware.....	9
2.1.2.1.6 Completing the Add Hardware.....	9
2.1.2.2 Manually Add Device.....	10
2.1.2.2.1 IP address is added hardware.....	10
2.1.2.2.2 Adding hardware serial number.....	11
2.1.2.3 edit device properties.....	12
2.1.2.3.1 modify the hardware device name.....	14
2.1.2.3.2 modify the hardware device port number, user name and password.....	15
2.1.2.3.3 Modify the channel name.....	15
2.1.3 Storage Configuration.....	17
2.1.3.1 configure the storage path, stream type, retention time.....	18
2.1.3.2 configure the recording type, time change.....	19
2.1.3.3 Configuration Template.....	19
2.1.4 Server Access.....	20
2.1.5 User Management.....	21
2.1.5.1 Edit User Information.....	21
2.1.5.2 Edit User Permissions.....	21
2.1.6 Service.....	22
2.2 client and operating instructions.....	23
2.2.1 Login.....	23

2.2.2 Live Preview.....	24
2.2.2.1 Live Preview Features.....	25
2.2.2.2 View switching video.....	25
2.2.2.3 Select a camera preview video.....	26
2.2.2.4 PTZ control.....	26
2.2.2.5 Video Window Toolbar Function.....	27
2.2.2.6 View polling.....	28
2.2.2.7 Full Screen.....	28
2.2.3 Playback.....	29
2.2.3.1 Playback Interface Features.....	29
2.2.3.2 platform video playback.....	30
2.2.3.2.1 switch views video playback.....	30
2.2.3.2.2 The limiting choose camera video playback.....	30
2.2.3.2.3 Video Search.....	31
2.2.3.2.4 video playback.....	31
2.2.3.2.4.1 synchronous playback.....	31
2.2.3.2.4.2 independent playback.....	32
2.2.3.2.4.3 loop playback.....	33
2.2.3.3 Export Video Platform.....	33
2.2.3.4 Device Playback.....	36
2.2.3.4.1 Select playback video camera.....	37
2.2.3.4.2 Video Search.....	37
2.2.3.4.3 video playback.....	38
2.2.3.5 Export recording equipment.....	39
2.2.4 Management function.....	39
2.2.4.1 Export List.....	39
2.2.4.2 View Settings.....	40
2.2.4.2.1 View Editor.....	40
2.2.4.2.1.1 New View.....	40
2.2.4.2.1.2 view content editor.....	41
2.2.4.2.1.3 Modify the view name.....	44
2.2.4.2.1.4 Delete View.....	44
2.2.4.2.1.5 Set View polling.....	45
2.2.4.2.1.6 Save Edit.....	45
2.2.4.2.3 System parameter settings.....	46
2.2.5 Logout.....	47

# 1 Installation

VMS consists of two parts, VMS VMS server and client, you can choose to install VMS VMS server

and client installed on the same computer, can also be installed separately on different local computer, select the default full installation.




## 2 VMS usage and operating instructions

### 2.1 server and operating instructions

#### 2.1.1 Login



Double-click on the desktop icon to start the server management program, start interface as the first use of VMS Management program, you need to create a superuser



Login to Management Application

HEROSPEED

The first landing of the system, please add users

User name:


Password:

Confirm Password:

☐ Save Username

Add Cancel

Use super-user or administrator user login VMS Management



Login to Management Application

HEROSPEED


User name: 1

Password:

☒ Save Username


Login Cancel

Successful landing into the management end of the main VMS Management Interface




## 2.1.2 Adding a hardware device


Click the entry, click Add Hardware



Pop-up dialog box to add add hardware, hardware scans can scan directly inside the LAN hardware device, you can also scan the specified network hardware; manually add the hardware is added directly to know the address or the serial number of hardware devices.




## 2.1.2.1 Adding scanning equipment




### 2.1.2.1.1 specified IP range scanning hardware

IP range can be set to filter search equipment, if you do not specify IP range can click Next to skip.




### 2.1.2.1.2 specify scanning hardware manufacturers

Can be set to search for equipment manufacturers, if you do not specify manufacturers can click Next to skip the default search All manufacturers




### 2.1.2.1.3 Configuring automatic verification

Add the default user name and password, and automatically verify scanned hardware devices (no need to configure automatic verification directly to the next step)




Pop-up dialog box to add a user name and password



#### 2.1.2.1.4 Start Depending on how the search appliance


Click Next.





### 2.1.2.1.5 Manual Verification hardware

Hardware manually enter your username and password click Start




### 2.1.2.1.6 Completing the Add Hardware

Select the desired device, then click Next to complete the search for new ways of equipment, software can add up to 256 channels



### 2.1.2.2 Manually Add Device



#### 2.1.2.2.1 IP address is added hardware

Enter the IP or domain name, port number, user name, password, and the number of channels to choose the type of new equipment Driver

**Add Hardware**

**Type IP addresses**

Type the IP addresses of the hardware you want to add to your system or import the information from a comma separated values(CSV) file. You can speed up the scanning process by selecting the manufacturer(s) of the devices you want to add.

Add Hardware Devices

Device Address	Port	User Name	Password	Channels	Driver
172.18.194.25	80	admin	•••••	1	Herospeed IPC
www.devices.com	80	admin	•••••	1	Herospeed DVR
	80			1	Auto-detect

Add P2P Devices

Serial number	User name	Password	Channels	Driver
			1	P2P IPC

Previous Next Cancel

## 2.1.2.2.2 Adding hardware serial number

Input Devices SN code to add P2P device

**Add Hardware**

**Type IP addresses**

Type the IP addresses of the hardware you want to add to your system or import the information from a comma separated values(CSV) file. You can speed up the scanning process by selecting the manufacturer(s) of the devices you want to add.

Add Hardware Devices


Device Address	Port	User Name	Password	Channels	Driver
	80			1	Auto-detect

Add P2P Devices

Serial number	User name	Password	Channels	Driver
11111111111111	admin	•••••	1	P2P IPC
			1	P2P IPC


Previous Next Cancel

Completed manually add devices, software can add up to 256 channels.



### 2.1.2.3 edit device properties

As shown below, click on the "1", double-click the "2"




Eject Hardware Properties dialog box

Hardware Properties

?

X



Name and Video Channels

Network, Device Type and License

Hardware name and video channels


Hardware name: 172.18.196.85

Enable	Camera
<input checked="" type="checkbox"/>	Camera 5


OK

Cancel

### 2.1.2.3.1 modify the hardware device name



### 2.1.2.3.2 modify the hardware device port number, user name and password




The screenshot shows the 'Hardware Properties' dialog box. On the left, a tree view has two items: 'Name and Video Channels' and 'Network, Device Type and License'. The 'Network, Device Type and License' item is selected and highlighted with a red box. The main area of the dialog is divided into two sections: 'Network' and 'Device type'. The 'Network' section contains fields for 'Address' (172.18.196.85), 'HTTP port' (80), 'RTSP port' (554), 'User name' (admin), and 'Password' (masked with dots). There are checkboxes for 'Use default HTTP port' and 'Use default RTSP port'. The 'Device type' section contains fields for 'Hardware type' (Herospeed IPC), 'Serial number (Mac address)' (06:E7:EF:7D:E9:45), and 'License information' (Trial). At the bottom right are 'OK' and 'Cancel' buttons.

Section	Field	Value
Network	Address	172.18.196.85
	HTTP port	80
	RTSP port	554
	User name	admin
	Password	.....
Device type	Hardware type	Herospeed IPC
	Serial number (Mac address)	06:E7:EF:7D:E9:45
	License information	Trial


### 2.1.2.3.3 Modify the channel name

As shown below, click on the "1", double-click the "2".





Open the Properties dialog box to modify the camera





## 2.1.3 Storage Configuration

Displays storage configuration information for all devices

**Video Manager System**

File Services Wizards Options Help

Getting Started Hardware Devices **Storage Information** Users Server Access Services Log Out

**Surveillance Server**

- Storage Information
  - Camera 1
  - Camera 2
  - Camera 3
  - Camera 4
  - Camera 5
  - Camera 6

**Camera Summary:**

Camera Name	Record On	Schedule	Retention Time	Recording Path	Archiving Path
Camera 1	Never		5 Day	C:/MMS/Record	C:/MMS/Archives
Camera 2	Never		5 Day	C:/MMS/Record	C:/MMS/Archives
Camera 3	Never		5 Day	C:/MMS/Record	C:/MMS/Archives
Camera 4	Never		5 Day	C:/MMS/Record	C:/MMS/Archives
Camera 5	Never		5 Day	C:/MMS/Record	C:/MMS/Archives
Camera 6	Never		5 Day	C:/MMS/Record	C:/MMS/Archives

**Storage Usage Summary:**

Drive	Path	Drive Size	Other Data	Free Space
C:/	C:/	48 GB	46 GB	2 GB
D:/	D:/	195 GB	126 GB	69 GB
E:/	E:/	221 GB	131 GB	90 GB
G:/	G:/	0 GB	0 GB	0 GB


Legend: ■ Free space ■ Other space

Archiving Times: 19:29:49

Add Delete

There are 0 channels has been configured to store information

Channel storage configuration editor, double-click to the right of the list box into the recording and storage properties, you can only give one camera configuration can also use templates to configure multiple cameras, (using the template configuration see 2.1.3.3).



### 2.1.3.1 configure the storage path, stream type, retention time

Recording and Storage Properties

Recording and Archiving Paths

Video Recording

Storage Information

**Recording**

Template

	Recording Path	Archiving Path	Recording stream	Retention Time
Template->	C:/VMS/Record	C:/VMS/Archives	Main stream	5 Day

Apply Template	Camera	Recording Path	Archiving Path	Recording stream	Retention Time
<input type="checkbox"/>	Camera 1	C:/VMS/Record	C:/VMS/Archives	Main stream	5 Day
<input checked="" type="checkbox"/>	Camera 2	C:/VMS/Record	C:/VMS/Archives	Main stream	5 Day
<input type="checkbox"/>	Camera 3	C:/VMS/Record	C:/VMS/Archives	Main stream	5 Day
<input type="checkbox"/>	Camera 4	C:/VMS/Record	C:/VMS/Archives	Main stream	5 Day
<input type="checkbox"/>	Camera 5	C:/VMS/Record	C:/VMS/Archives	Main stream	5 Day
<input type="checkbox"/>	Camera 6	C:/VMS/Record	C:/VMS/Archives	Main stream	5 Day

Select All Clear All

Set all template values on selected cameras: Set

OK Cancel

### 2.1.3.2 configure the recording type, time change

Recording and Storage Properties

Recording and Archiving Paths  
Video Recording  
Storage Information

Video recording

Template

		Record on	Schedule	Pre-recording	Second(s)	Post-recording	Second(s)
	Template->	Motion detection	ALWAYS	<input type="checkbox"/>	3	<input type="checkbox"/>	3

Apply Template	Camera Name	Record on	Schedule	Pre-recording	Second(s)	Post-recording	Second(s)
<input type="checkbox"/>	Camera 1	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3
<input type="checkbox"/>	Camera 2	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3
<input type="checkbox"/>	Camera 3	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3
<input type="checkbox"/>	Camera 4	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3
<input type="checkbox"/>	Camera 5	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3
<input type="checkbox"/>	Camera 6	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3

Select All Clear All

Set all template values on selected cameras: Set

OK Cancel

### 2.1.3.3 Configuration Template

As shown below:

- 1> Edit Template
- 2> Select the template you want to apply the camera
- 3> settings to the camera

Recording and Storage Properties

Recording and Archiving Paths  
Video Recording  
Storage Information

Video recording

Template

	Record on	Schedule	Pre-recording	Second(s)	Post-recording	Second(s)
Template->	Motion detection	ALWAYS	<input type="checkbox"/>	3	<input type="checkbox"/>	3

Apply Template	Camera Name	Record on	Schedule	Pre-recording	Second(s)	Post-recording	Second(s)
<input type="checkbox"/>	Camera 1	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3
<input type="checkbox"/>	Camera 2	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3
<input type="checkbox"/>	Camera 3	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3
<input type="checkbox"/>	Camera 4	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3
<input type="checkbox"/>	Camera 5	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3
<input type="checkbox"/>	Camera 6	Never		<input checked="" type="checkbox"/>	3	<input checked="" type="checkbox"/>	3

Select All Clear All

Set all template values on selected cameras: Set

OK Cancel

## 2.1.4 Server Access

The port number set the local VMS SmartClient for landing

Video Manager System

File Services Wizards Options Help

Getting Started Hardware Devices Storage Information Users Server Access Services Log Out

Server Access Summary:


Server Name	Local Port	Internet Access	InternetAddress	Internet Port	Max. No. of Clients
Server	8685	<input type="checkbox"/>		1025	100

There are 0 channels has been configured to store information

## 2.1.5 User Management

### 2.1.5.1 Edit User Information

Users list management, open the User List window



**Add New Users**

**Add users**  
choose "Basic Users",it can be used for client login"  
choose "Administrator Users",it can be used for landing and configuration management"

**Add user**

User name:

Password:

Confirm Password:

☐ Administrator Users ☒ Basic Users

**Add User**

User name	Editor	Delete
1	Editor	Delete

**Back** **Finish** **Cancel**


Users can be added in the window, modify users, delete users.

When new users can choose two types of users,

- 1: Administrator user (VMS Management can be used for landing and landing VMS SmawtClient),
- 2: normal user (used only for landing VMS SmartClient).


### 2.1.5.2 Edit User Permissions

You can set permissions and equipment VMS SmartClient on the channel to the specified user



## 2.1.6 Service

Background VMS Server Control Program




VMS Server can control the use of state, only to be turned back at the video store, VMS SmartClient client to normal use

## 2.2 client and operating instructions

After VMS Management configuration is complete, you can use VMS SmartClient video preview and playback clients, VMS SmartClient with VMS Management can be installed on the same machine can also be individually installed on the other machine

### 2.2.1 Login

Enter VMS Management machine where IP and port number (if it is installed on the same machine, IP is 127.0.0.1, port number 80 by default, when the server access ports on VMS Management is changed, the port number to use consistent )

A screenshot of a 'Connect to Server' dialog box titled 'VMS Monitor Login'. The dialog has a dark background with white text. It contains three input fields: 'Server Address' with the value '127.0.0.1:8685', 'User' with the value '1', and 'Password' which is empty. Below these fields are two checkboxes: 'Remember Password' (checked) and 'Auto Login' (unchecked). At the bottom right are two buttons: 'Connect' and 'Cancel'. The 'Server Address' and 'User' fields have red boxes highlighting their values.

Connect to Server

# VMS Monitor Login

Server Address: 127.0.0.1:8685

User: 1

Password:

☒ Remember Password

☐ Auto Login

Connect Cancel

On VMS Management user to create login authentication

Connect to Server

VMS Monitor Login

Server Address

127.0.0.1:8685

User

1

Password

•

☒ Remember Password


☐ Auto Login

Connect

Cancel


## 2.2.2 Live Preview

Live Preview Interface






### 2.2.2.1 Live Preview Features



- 1> Logout: Exit the current user to return to the login screen.
- 2> View round robin: All round robin round robin set up view
- 3> Image size:
  - a. routine: The image is displayed in real scale.
  - b. Stretch: The image is displayed in the window size.
  - c. 1 times: the image is not scaled.
  - d. 2 times: 2 times image to enlarge.
  - e. 3 times: 3 times image to enlarge.
- 4> View: Select the type of layout view window.
- 5> Snapshot: snapshot picture of the current window.
- 6> Close the current camera video.
- 7> PTZ control (only enabled devices that support PTZ control is effective).
- 8> Full Screen: Full-screen view


### 2.2.2.2 View switching video

User set a good view layouts to quickly switch view preview video




### 2.2.2.3 Select a camera preview video

Select the camera onto the specified window preview video




### 2.2.2.4 PTZ control

- Select the required PTZ control window.
- In the PTZ console window for the selected PTZ control.




## 2.2.2.5 Video Window Toolbar Function

- stop the current window and open video
- Image capture
- Local Recording
- talkback
- sound.
- Stream Switching
- digital zoom




### 2.2.2.6 View polling

Click the button to open the round robin round robin view, click again to close the round robin.



### 2.2.2.7 Full Screen

Click to view full-screen to enter full screen mode, right-click on the screen to exit full-screen button to exit full-screen mode




## 2.2.3 Playback

Playback is divided into platform video playback and video playback devices.

Under VMS platform playback only in case of server configuration can have playback device playback only in the case of video equipment to playback.

### 2.2.3.1 Playback Interface Features




- 1> Location: Depending on the selected time position quickly locate to a specified location
- 2> image size
  - a. routine: The image is displayed in the actual proportion
  - b. Stretch: The image is displayed in the window size
  - c. 1 times: the image is not scaled
  - d. 2 times: 2 times image to enlarge
  - e. 3 times: 3 times image to enlarge
- 3> Snapshot: Save the currently selected video playback window
- 4> Export
  - a. playback platform to export the currently selected playback video window, select the time period
  - b. equipment playback in the export file selected in the list of video files
- 5> Device: Enter the playback interface device
- 6> Full screen: view into full screen mode

## 2.2.3.2 platform video playback


### 2.2.3.2.1 switch views video playback

View user edited video playback fast switching




### 2.2.3.2.2 The limiting choose camera video playback

Select the desired camera onto the specified window




### 2.2.3.2.3 Video Search

Enter playback interface or playback interface switching view, the view will automatically search out all the time in the video window, and displayed on a timeline



Timeline of type:

- 1> in the timeline shows the currently selected window video timeline.
- 2> In the following timeline shows the current view all the video cameras and the timeline set.




### 2.2.3.2.4 video playback

#### 2.2.3.2.4.1 synchronous playback

Click the play button to start video playback, the playback mode to view simultaneous playback, the view in the window will play back video at the same time






Synchronous playback function Toolbar description:



1> Playback area: You can select the playback range, in this range loop playback.



2> 1 multiple playback: fast switching to a multiple of the playback.

3> Playback multiple adjustments.

4> Quick search video.

5> Start / pause playback.

6> single-frame playback.

7> The current window of the first video segment.

8> The current window of ten Previous video segment.

9> The current window of the next video segment

10> The current window of the finally video segment


11> The timeline display range.

## 2.2.3.2.4.2 independent playback

If you only need a video playback window, you can use a separate playback. Independent playback video window will not be synchronized playback control toolbar. Independent playback window in the simple playback control bar.


Independent playback window in the window toolbar, click the independent playback button to playback individually





### 2.2.3.2.4.3 loop playback

You can specify a time range for continuous loop video playback.




### 2.2.3.3 Export Video Platform


You can export the video server in the client on demand. You can export the view in the window of a video recording, video can also be exported in view of all of the video window.

Video exported for use:


- 1> Select the time range you want to export.




2> Select to export video window.




3> Click the Export button.




4> Select the name and location of the exported.



5> After the export is completed in management functions in the export list to view details



## 2.2.3.4 Device Playback




- 1> Select the channel to be played back in the device list and drag the playback window (5)
- 2> select the date to be played back
- 3> Select recording type
- 4> Video Search
- 5> Playback Window
- 6> Recording Schedule
- 7> Select synchronous control video playback
- 8> Video Playback speed control
- 9> Recording Playback Controls

10> View Control


### 2.2.3.4.1 Select playback video camera

Select playback video camera




### 2.2.3.4.2 Video Search

After dragging the camera view automatically search out all the windows in the view to set the date of the recording time, and displayed on a timeline




### 2.2.3.4.3 video playback

Click the play button to start video playback of the currently selected window




Function Playback Toolbar description:



- 1> synchronization control: When selected, the playback control is valid for all windows
- 2> Playback Speed: Adjust the playback speed of video
- 3> playback control: playback of video control start, pause, stop, single frame playback, video playback of the first segment, a video playback section, a video playback section, a video playback of the last paragraph
- 4> View options: choice of single window view, 4, and 16 window view window view
- 5> Timeline: Displays recording time
- 6> Adjust Timeline Display: 16-window view, click scrollable window display other time



## 2.2.3.5 Export recording equipment




- 1> Click "File List" arrow
- 2> Select Export Video window
- 3> Select the video file you want to export
- 4> Click Export

## 2.2.4 Management function


### 2.2.4.1 Export List

See video of the export list information



## 2.2.4.2 View Settings

The role of view is that you can pre-edit content layout and views good views, quickly switch the video area. And there will be saved to the VMS platform for later use





### 2.2.4.2.1 View Editor

#### 2.2.4.2.1.1 New View


Click the Add button to select the desired view layout type






#### 2.2.4.2.1.2 view content editor


There are four types of views content, 1 Camera 2 Image, 3. HTML page 4 video carousel  
Select the view for editing




- 1> Set View window to add a video device, select the camera, onto the target window to complete the video to add.




- 2> Set the page view window to add text
  - a. Click on other items
  - b. Select the "HTML page"
  - c. Drag the specified window
  - d. Enter the web address



- 3> Set View window Add image
  - a. Select the "Image"
  - b. Drag a specified window
  - c. Select a picture




- 4> Set window view window to add round robin
  - a. Select the "round robin"
  - b. Drag a specified window
  - c. Select the desired window polling device
  - d. Set the video window polling time
  - e. Set the video stream type




### 2.2.4.2.1.3 Modify the view name

Double-click to modify the view to enter edit mode, modify the view name




### 2.2.4.2.1.4 Delete View

Select the Right View pop-up menu select Delete View




#### 2.2.4.2.1.5 Set View polling

- 1> select the "Turn round robin"
- 2> set the polling interval
- 3> Set the video polling stream




#### 2.2.4.2.1.6 Save Edit

Rear view of editing you must remember to click Save to take effect



### 2.2.4.3 System parameter settings




Login Options: You can set whether to remember the password, whether automatic landing

Language options: Set the system language

Storage Options: Set the capture, video recording and video export path

Other: Set whether to automatically maximize the window as the primary stream playback

## 2.2.5 Logout



1. Quit System
2. Log out of the system